Business Analyst ™ Quick Reference Guide












Table of Contents

Brief Key Tour 1	
Basic Operations	ı
Memory Operations 3	3
Statistical Mode 3	3
Financial Mode 5)
Common Keystroke Sequences 7	,
Monthly Payment for Home	
Mortgage 7	
Remaining Balance for Home	
Mortgage 8	,
Purchasing a Commercial Bond	
on an Interest Date 10	
Implicit Interest Rate of a Lease 12	
Net Present Value for Variable	
Cash Flows 10. Joen Woorne 13	
Battery Information	

Business Analyst Quick Reference Guide

Always refer to the *Business Analyst Guidebook* for complete details and examples of calculator operation.

BRIEF KEY TOUR

Basic Operations

- ONCE Turns on the calculator. Pressing a number key clears the value shown in the display. Pressing ONCE twice, or once after an operation or function key (including), clears the display and any pending operation. Pressing ONCE when "Error" is shown clears the display and any pending arithmetic calculation. For more details on error conditions, see Appendix C of the Business Analyst Guidebook.
- 2nd Decimal Changes the displayed decimal places from fixed two to floating decimal and vice versa. When the decimal point is fixed to two places, the "DEC 2" indicator appears in the display.
- press number × percentage when you press number × percentage %=, add-on percentage when you press number + add-on percentage %=, and discount percentage when you press number discount percentage %=.

2nd 40%—Calculates the percentage of change between the first and second numbers with respect to the second number when entered as follows.

The value found equals

$$\frac{X_1 - X_2}{X_2} \times 100$$

- —Calculates the square root of the displayed number. (The displayed number cannot be negative.)
- 2nd x2—Calculates the square of the displayed number.
- (½) Computes the reciprocal of the displayed number. (The displayed number cannot be zero.)
- 2nd inx Calculates the natural logarithm (base e) of the displayed number, x. (x cannot be negative or zero.)
- 2nd c'—Calculates the natural antilogarithm (raises e to the xth power) of the displayed number.
- —Raises any positive number to any power. To use this key:

Enter the number to be raised to a power, y.

Press [y*].

Enter the power, x.

Press =.

2nd x! — Calculates the factorial of any positive integer less than 70.

Memory Operations

- ONC STO Clears the display and clears memory by storing a zero. Turning off the calculator does NOT clear the memory.
- Stores the displayed value in the memory.
- Recalls the value in memory to the display. (The value in memory is not changed.)
- —Adds the displayed value to the value in the memory.
- Exc Exchanges the displayed value with the value in the memory.

Statistical Mode

- and STAT Places the calculator in the statistical mode. The "STAT" indicator appears in the display. If the calculator is already in the statistical mode, this key sequence clears the statistical registers.
- Σ+—Enters data points for statistical calculations. After you press Σ+, the calculator displays the current number of data points entered.
- 2nd 2nd Removes unwanted data points from the stored data sequence. After you press 2nd, the calculator displays the current total of stored data points.
- FRQ Enters or removes multiple identical data points.

The procedures used to enter and remove statistical data are shown in the following chart.

SINGLE-VARIABLE DATA

1. To Enter Single Occurrence Data Points

- · Enter data point.
- Press T+.
- · Repeat for next data point.

2. To Remove Single Occurrence Data Points Entered

- · Press ON/c.
- · Enter unwanted data point.
- Press 2nd X-.

3. To Enter Multiple Occurrence Data Points

- · Enter data point.
- · Press FRQ.
- · Enter number of repetitions.
- Press T+.
- Repeat for next data points.

4. To Remove Multiple Occurrence Data Points Entered

- · Press ON/C.
- Enter unwanted data point.
- · Press FRQ.
- · Enter number of repetitions.
- Press 2nd I-
- —Calculates the mean (average) of the entered data.
- On—Calculates the standard deviation with n weighting (for populations) of the entered data.

- on-1—Calculates the standard deviation with n − 1 weighting (for samples) of the entered data.
- on 2nd 22—Calculates the variance of a population (n weighting).

Financial Mode

- Places the calculator in the financial mode. The "FIN" indicator appears in the display. If the calculator already is in the financial mode, this key sequence clears the financial registers.
 - —Enters the number of payment or compounding periods.
- —Enters the periodic interest rate per compounding period for compound interest calculations and per payment period for annuities.
- PMT—Enters the payment amount in ordinary annuity or annuity due calculations. The payment must be zero in compound interest calculations so the calculator performs the correct financial computation. The "ANN" indicator appears in the display when the payment value is not zero.
- PV Enters the present value.
- FV Enters the future value.
- CPT Used with the unknown value key to calculate compound interest or ordinary annuities.
- OUE Used with the unknown value key to calculate annuities due.

To use the financial keys, be sure the calculator is in the financial mode by pressing 2nd 2ND. This also clears the financial registers. Three of the values N, %i, PMT, PV, or FV, must be entered with the sequence

value, financial key before an unknown value can be computed by pressing

CPT financial key for unknown for compound interest or ordinary annuity situations, or by pressing

financial key for unknown for annuity due situations.

- 2nd NI—Calculates the interest paid for the payment number entered in the display. It may be used with CPT for ordinary annuities or DUE for annuities due.
- 2nd DAL Calculates the balance remaining on the loan principal after the specified payment. It may be used with CPT for ordinary annuities or OUE for annuities due.
- rates to annual effective rates. Enter the number of compounding periods per year, press 2nd APPN, enter the annual percentage rate, and press = to calculate the annual effective rate.
- 2nd ← Converts annual effective rates to annual percentage rates. Enter the number of compounding periods per year, press 2nd ← cr, enter the annual effective rate, and press = to calculate the annual percentage rate.

COMMON KEYSTROKE SEQUENCES

Monthly Payment for Home Mortgage

Purpose: To find the amount of the monthly payment on a home mortgage loan when payments are made at the end of each month (ordinary annuity).

Time-Line Diagram:

PV	PMT = ?	PMT = ?	PMT = ?
0	1	 N - 1	N

Values You Supply:

- number of years of mortgage
 - annual interest rate
- mortgage amount

Procedure Key Sequence

- Clear calculator and select financial mode.
- Enter mortgage amount
- 3. Calculate monthly interest rate and enter as % i.

rate ÷ 12

 Calculate number of payments and enter as N.

years X 12

ON/c 2nd FIN

mortgage PV

Compute monthly payment.

CPT PMT *

*If payments occur at the beginning of each month (annuity due), press DUE PMT to compute the monthly payment.

Reference: "Solving for Payment," Chapter 15, Business Analyst Guidebook.

Remaining Balance for Home Mortgage

Purpose: To find the remaining balance of a regular mortgage when payments are made at the end of each month (ordinary annuity).

Time-Line Diagram:

			FV = ?
PV	PMT	 PMT	PMT
0	1	N - 1	N

Values You Supply:

- number of payments made
- · annual interest rate
- · mortgage amount
 - amount of payment

Procedure

Key Sequence

 Clear calculator and select financial mode.

ON/c 2nd FIN

 Calculate interest rate per payment period and enter as %i.

rate ÷ 12

Enter payment amount.

payment PMT

Enter mortgage amount.

mortgage PV

N

Enter number of payments made.
 Compute remaining

Compute remaining balance.*

a. Using future value key. 2010 Joerg Wolfft

b. Using balance key.

CPT 2nd BAL

*If payments occur at the beginning of each month (annuity due), press OUE FV or OUE 2nd BAL to compute the remaining balance.

Reference: "Solving for Remaining Balance (Balloon)," Chapter 15, Business Analyst Guidebook.

Purchasing a Commercial Bond on an Interest Date

Purpose: To calculate the purchase price of a bond sold on an interest date with more than one coupon payment remaining.

Time-Line Diagram:

			+ V
PV = ?	PMT	 PMT	PMT
0	1	N – 1	N

Values You Supply:

- · number of years until bond matures
 - number of coupon periods per year
 - · required yield to maturity
 - · par (face) value of bond
 - bond's coupon rate

Procedure

- Key Sequence
- Clear calculator and select financial mode.
- ON/C 2nd FIN
- Calculate and enter yield per coupon period.

yield ÷
coupon
periods/year
= (%i)

Calculate and enter coupon payment.

coupon rate
% ÷
number of
coupon
payments per
year × par

 Calculate and enter number of coupon graywords.

years X
number of
coupon
payments per
year N

5. Enter redemption (par) value.

par FV


6. Compute bond price.

Reference: "Price of a Bond Sold on a Coupon Payment Date," Chapter 10, Business Analyst Guidebook.

Implicit Interest Rate of a Lease

Purpose: To find the interest rate that discounts the lease payments and residual value back to an amount equaling the asset's market value.

Time-Line Diagram:



Values You Supply:

- · market value or cost of asset
- · periodic lease payment
- · number of lease payments
- · residual value

Key Sequence Procedure

- 1. Clear calculator and select financial mode.
- 2. Enter asset market value.
- 3. Enter periodic payment.
- 4. Enter number of payments.



- cost PV
- payment PMT
- number of payments N
- 5. Enter residual value. 6. Compute implicit in-
- terest rate per payment period.*

value FV DUE 0/01

*If payments occur at the end of each month (ordinary annuity), press CPT %i.

Reference: "Implicit Interest Rate." Chapter 14, Business Analyst Guidebook.

Net Present Value for Variable Cash Flows

Purpose: To find the net present value of an asset with variable cash flows.

Time-Line Diagram:

Values You Supply:

- · hurdle rate
 - period number when cash flow occurs
- amount of operating cash flow for each period
- initial cash outlay to purchase asset

Procedure

Key Sequence

1. Clear calculator and select financial mode.

ON/c 2nd FIN

2 Enter burdle rate

3. Calculate present value of first cash flow.

a. Enter period number when cash flow occurs as N b. Enter amount of cash flow as FV. c. Compute and store present value. rate (%i)

period N

cash flow FV CPT PV STO

4. Calculate present value of other cash flows. Repeat this step until you compute present value of all cash flows Add results to memory.

a. Enter period alculator Museum number when cash flow occurs. b. Enter amount of cash flow. c. Compute present value and add to memory.

period N

cash flow (FV)

CPT PV SUM

5. Recall present value total and subtract initial cash outlay to calculate net present value of cash flows.

RCL - outlay

Reference: "Net Present Value, Unequal Cash Flows." Chapter 11. Business Analyst Guidebook.

BATTERY INFORMATION

The calculator uses two of any of the following batteries for as many as 1000 hours of operation: Panasonic LR-44, Ray-O-Vac RW-82, Union Carbide (Eveready) A-76, or the equivalent. For as many as 2500 hours of operation, use Mallory 10L14, Union Carbide (Eveready) 357, Panasonic WL-14, Toshiba G-13, Ray-O-Vac RW-42, or the equivalent. Refer to the Appendix of the Business Analyst Guidebook for battery replacement instructions.

© 2010 Joerg Woerner Datamath Calculator Museum © 2010 Joerg Woerner Datamath Calculator Museum © 2010 Joerg Woerner

Datamath Calculator Museum



TEXAS INSTRUMENTS

DALLAS, TEXAS

PRINTED IN U.S.A.

1048779-1