

FUN WITH VOWEL POWER!



another fun activity book

Speak Spell

MY KEYS



Turns me on and tells me you want to spell some words.



Tells me you're ready to begin.



Tells me to check your spelling.



see "Fun With Words" or the accompanying Parents' Letter.

For complete instructions for using Speak & SpellTM

Lets you hear a word again.



Erases the letters in my window.



I'll repeat the same 10 words again.



I'll show you 10 words, ask you to say them, and then spell them.



I'll think of a letter and put it in my window.



I'll change the word in my window to code.



I'll think of a word and you try to guess it.



I'll give you one of the letters in the mystery word.



Puts an apostrophe in my window.



Turns me off.



When a new word list
(called a module) is placed
under my batteries, pressing

(#) MODULE SELECT tells me
to give you words from
this new list. Pressing
(#) MODULE SELECT again
tells me to go back to my

built-in word list.



MEET THE VOWELS!

Vowels are very special letters. They turn other letters into words. All words have at least one vowel.

Vowels can make many sounds. My Vowel Power module has a level for each kind of vowel.

LEVEL A -SHORT VOWEL WORDS

Most of the time when a vowel says a sound other than its name, it is a short vowel sound. For example,

class 18ma

help switch clock

much

LEVEL B -LONG VOWEL WORDS

When vowels say their names in a word, they are called long vowels. Like,

name 100

Cright / USEUM

unite

LEVEL C — 2-LETTER VOWEL WORDS

Sometimes two vowels (and y and w) work together to make a new vowel sound. Like,


oo — cook, smooth oi.oy — point, toy au.aw — cause, draw ou.ow — cloud, clown

LEVEL D — VOWEL-R WORDS

When R follows a vowel, it changes the vowel's sound. Like,

smart germ third snore

church



The animals are loose. I think they are hiding in the word list. Will you help me put them in their cages? Here's how:


1. Use the 1 SECRET CODE key to find out what is in the word list. (Press my (H) and 1 SECRET CODE keys. Press the letter keys to spell the coded word, then press

into the animal's name. Press ERASE before you do the next word.)

2. Say the animal name and listen for a long or short vowel sound. Then look in the long and short vowel cages for a letter clue to see where the animal lives.

3. When you find the right cage, fill in the animal's name.

4. Follow the dots to draw the animal. (†) ENTER. I'll change the code LONG VOWEL ANIMALS Strittly 111. Alla hall traiting 24 21 22 interesti Partice sugate fratte in institutions 25



You will need two players and several markers (buttons, pennies, etc.). Decide who is at bat first. I'll be the pitcher.

When it is your turn at bat, press my (ON), (#) MODULE SELECT, (D) and

© keys. Each word you spell correctly is a hit. If the word has an ar — move

one base; er or ir – move two bases; or – move three bases; and ur – is a home run.

Use your markers as the men on base. If you misspell a word — it is an out.


Change turns after three outs or ten words (whichever is first). Count the number of markers that cross home

plate and add them to your score. The player with the highest score after three turns


is the winner. In case of tie, play another inning.













You will need:

- two or more people
- a marker (a button or penny will do) for each player


Put your marker on START and decide who goes first.


When it is your turn, press my (2) LETTER key. If I give you a


consonant, move your marker one space. If I give you a vowel, move your marker two spaces.

Each time you land on a new space, do what it says. If you don't get the right answer, skip your next turn.

Take turns playing until one player reaches Earth and wins.









I've forgotten how to open the door to spelling. Will you help me?

Here's how:


- Use a red crayon, marker, or pencil to color all the squares that have consonants.
- Use a yellow crayon, marker or pencil to color all the squares that have vowels.

The secret to tell you how to unlock the door to spelling will appear.

				-	-																11
Q	W	R	T	Y	P	S	D	F	E	0	A	I	G	Н	J	K	L	Z	х	С	V
В	0	I	U	N	M	Q	w	R	U	T	Y	P	S	D	F	G	Н	A	I	E	J
K	A	L	E	Z	C	V	В	N	I	A	U	M	Q	W	R.	T	Y	P	0	S	D
F	0	U	I	G	Н	1	K	L	0	X	C	v	В	N	M	Q	W	R	U	T	Y
P	U	S	A	D	F	G	H	J	U	A	E	at	K	L	Z	X	C	E	0	A	V
В	N	M	Q	W	R	T	Y	P	S	D	F	G	Н	J	K	L	Z	X	С	V	В
N	M	Q	W	E	U	I	0	R	T	Y	P	S	D	A	D	F	U	G	Н	J	K
L	Z	X	С	A	V	В	E	N	M	Q	W	С	R	E	T	Y	I	P	S	D	F
G	Н	J	K	I	L	Z	U	X	C	v	В	N	M	I	Q	w	0	R	T	Y	P
S	D	F	G	0	н	J	I	K	L	Z	X	С	V	0	В	N	A	M	Q	w	R
T	Y	P	S	U	A	I	E	D	F	G	Н	J	K	U	I	0	E	L	Z	X	С
V	В	N	M	Q	w	R	T	Y	P	S	D	F	G	Н	J	K	L	Z	X	C	V
E	U	I	0	A	U	I	0	A	E	I	0	A	E	U	0	A	E	U	I	0	A
В	N	M	Q	W	R	T	Y	P	S	D	F	G	Н	J	K	L	Z	X	C	V	В
N	E	U	I	0	M	Q	A	U	I	0	w	R	T	Y	P	S	D	F	G	Н	J
K	A	L	Z	U	X	E	U	I	0	A	E	С	V	В	N	M	Q	W	R	T	Y
P	U	I	0	A	S	E	0	D	F	E	I	0	U	A	I	E	0	A	U	E	D
F	E	A	G	Н	J	I	A	K	L	0	E	A	I	0	U	A	U	I	0	Z	X
С	0	V	I	В	N	A	E	I	0	U	E	N	M	E	Q	I	W	A	R	T	Y
P	I	S	D	A	F	G	0	E	I	A	Н	J	K	L	Z	X	С	V	В	N	M
Q	W	R	T	Y	P	S	D	F	G	Н	J	K	L	Z	X	C	V	В	N	M	Q

Battery Information

Four "C" size alkaline batteries are required. If another type of "C" size batteries are used, remove them immediately after they are discharged or when storing your *Speak & Spell* to prevent possible damage from leakage.



Remove the battery compartment door by prying gently with a small screwdriver, key, coin, or similar object. Follow the instructions on the floor of the battery compartiment.

© 2010 Joerg Woerner Datamath Calculator Museum

Low Battery Indication

Speak & Spell will provide approximately 15 hours of actual use when using alkaline batteries. If you observe any of the following indications, the batteries should be replaced:

- 1. Erratic or dim display;
- 2. Erratic performance;
- 3. Imprecise word pronounciation, or unusual and unexpected sounds or tones;
- 4. Pressing the keys has no effect;
- 5. Unusual or inconsistent operation.

In Case Of Difficulty

- 1. Check to make sure that Speak & Spell is on.
- 2. Check the low battery indications.
- 3. If display is blank and pressing the keys has no effect, remove all batteries and re-install. If operation is not restored, replace the batteries.
- If the batteries are new and properly installed, review the operating instructions to be certain that operating steps are followed correctly.
- 5. Refer to paragraph 2, page 3, "Module Select".

If none of the preceding procedures corrects the difficulty, return your *Speak & Spell* prepaid and insured to the applicable Service Facility.

For your protection, the learning aid must be sent insured. Texas Instruments cannot assume any responsibility for loss of or damage to uninsured shipments.

Please include information on the difficulty experienced with the learning aid, as well as return address information including name, address, city, state and post code. The shipment should be carefully packaged and adequately protected against shock and rough handling.

Word List

The Vowel Power vocabulary is divided into four categories. Level A is short vowel words, Level B long vowel words, Level C contains 2-letter vowel words, and Level D Vowel-R words.

When the (#) MODULE SELECT key is pressed and the "SPELL" and "SAY IT" activities played, Speak & Spell will choose ten words randomly from the level chosen.

Level A	back bath bell brick brush cash catch chest chin class	clock crash crutch desk drink flag flash impact itch king	lunch match much neck pitch plunge ranch robin scratch	shed six smack steps switch tennis went wreckage yell
Level B	amuse argue beehive cane dream five high	jail kite name nine paint right scold	shape shine skylight slide smoke snow soap	strain three thoast true Sounite wheel
Level C	bound cause choice cloud clown cook couch count down draw	found gown haunt house join look moist mouse mouth	noise noun ounce point pound rough saw scout scowl	shawl shout sound spoil stout tall taught toy yawn
Level D	barge bird card chart church churn clear corner dirt doctor	fear first germ hurt near nerve north nurse roar scare	scarf score shore short silver smart snore spare spear	steer storm third thirst torch urge worm yard year



TEXAS


	Country	Pays Paese Maa Pais
Frist Name Vorname Prehom Nome Premisson Fundan Fundan		Codigo postale Postcode Postnumero Codigo postal D. Postal
Last Name Familianname Nom Cognome Achternam Efternam Efternam Efternam Ulturo nome Appellidos Address Indirizzo Adresse	Date	Citan

LET'S CHART YOUR PROGRESS!

Here's a special page to help you keep track of your spelling scores.

When you finish spelling ten words, write the level you used $(A,B,C,\operatorname{or} D)$ on the line at the bottom of the graph. Then find the number of words you spelled correctly on the left side of the graph. Follow the dotted line to color a bar from the bottom of the graph to the number you got right.

This bar graph will help you see how well you are doing.



© 2010 Joerg Woerner

Datamath Calculator Museum

