


# LCB-841


---



INSTRUCTION MANUAL

---

---



## Table of contents

Function and memory keyboard	Page 3-4
Introduction to checkbook calculator	Page 5
Maintenance and power source	Page 6
Special features and decimal system	Page 7
Clear key and math functions	Page 8
Percent (%) key	Page 9-10
Constant function operation	Page 11
Three checkbook memories	Page 12
Using checkbook memories	Page 13-15
Grand total display	Page 16
Checking and charge account calculator entry (example)	Page 17-18
Memory use for personal budget (example)	Page 19-20

## Numeric function and memory keys

### Numeric and function keys

7 8 9

4 5 6

1 2 3

0 . =

International keyboard  
with decimal point key  
and result key

ON

Turn on

OFF

Turn off

CE/C

Total clearing/  
individual entry clearing

+

Plus key

-

Minus key

%

Percentage key

×

Multiplication  
key

÷

Division  
key

=

Result key

## Numeric function and memory keys

Function and  
independent  
memory keys

**A/F**

Add mode  
floating decimal  
system change key

**M-**

Memory  
Minus

**CHK**

Check key  
memory #1

**M-**

**CHG**

Charge key  
memory #2

**M-**

**CHG**

Charge key  
memory #3

**M+**

Memory  
Plus

**DEP**

Deposit key  
memory #1

**M+**

**PMT**

Payment key  
memory #2

**M+**

**PMT**

Payment key  
memory #3

**MR**

Memory  
Recall

**BAL** 1

Balance key  
memory #1

**MR**

**BAL** 2

Balance key  
memory #2

**MR**

**BAL** 3

Balance key  
memory #3

**GT**

Grand total key  
all three memories

### Introduction

Congradulations, you are the owner of a fine quality electronic calculator specially designed to keep an electronic record of your daily personal finances. The LCB 841 checkbook calculator gives you the back-up capability of keeping status of your checking or savings accounts, personal budget, or special income and expenses records stored in 3 independent memories of your calculator wherever you go. Information can be stored in the permanent memories continuously, whether the calculator is on or off as long as the batteries are live. This 3 memory capability is available to you in addition to the standard calculator features which allow computation of everyday math problems and percentage calculations.

Careful reading of this instruction manual will enable you to use your new ROYAL calculator to its fullest capability. The checkbook calculator will become a valuable tool for managing your personal finances on a daily basis.

Datamath Calculator Museum

## Maintenance and power source

---

### Maintenance

Please read the following recommendations to insure trouble-free operation of your ROYAL calculator.

- Clean your calculator using a soft dry cloth. Do not use organic solutions such as alcohol.
- Your calculator should be kept in areas free from extreme temperature changes, dusty and damp areas.
- Should service of your calculator be required, use only an authorized ROYAL Service Center (see enclosed warranty card).

### Power source and battery replacement

Your LCB 841 will operate for approximately 1000 hours on a set of batteries. IMPORTANT! A fading or slow display will be noticeable prior to the loss of battery life. To replace your batteries, unscrew the small battery compartment cover plate on the back of your calculator and insert batteries with the positive side facing up. Your calculator uses two of any of the following button cell batteries: G-10, Eveready 389, Mallory 10L122, or Rayovac RW49. Replace battery compartment cover.

### Special features

**ON** and **OFF** KEYS – Your calculator is equipped with **ON** / **OFF** keys for control of power. Pressing the **OFF** button clears all operating entries except the checkbook memories.

Your calculator is also equipped with **Automatic Shut Off** which activates after a calculation pause of approximately 7 minutes in order to extend battery life.

### Add mode and floating decimal system

**ADD MODE** – Pressing **ON** key automatically places your calculator in Add Mode indicated by symbol (AM) in the display. The Add Mode (AM) feature is for your convenience when adding or subtracting dollars and cents; the decimal place is automatically set two places to the left.

**FLOATING DECIMAL SYSTEM** – It is recommended to depress the **A/F** key to change to the floating decimal mode when you wish to do multiplication, division, or percent calculation. The automatic floating decimal system allows entry of specific decimal figures. The calculator will automatically place the decimal point to the right of any number entered.

**DECIMAL KEY** – When the decimal key  $\cdot$  is pressed, the decimal point is fixed in that place and any further numbers entered will appear after the decimal point as a decimal fraction.



## Clear key and math functions

### Clear key

Press once to clear an incorrect entry, press twice to clear all calculation registers except the permanent memories.

### ERROR CONDITION (CAPACITY OVERFLOW)

Error condition is indicated by the letter "E" in the left corner of the display and is caused by the entering of a calculation which exceeds the capacity of the calculator.

1. The "E" symbol means that the first 8 digits of the result are correct but the decimal point must be placed 8 digits to the right.
2. Dividing any number by zero results in an error condition.
3. When error condition occurs the keyboard is locked to prevent further entries to eliminate erroneous results. Depressing the **CE/C** key once will release the keyboard lock so that the displayed number can be used in subsequent calculations. Depress the **CE/C** key twice to clear the registers.

### Add, subtract, multiply and divide

To perform the above functions, the operator simply enters the calculation as he or she would write it out.

Example: first number, calculation **+** **-** **x** **÷** second number, equal key **=** for result. This does not apply to chain calculation, however. In this case, the algebraic rules apply.

Example:

$$4 + 2 = 6$$

$$4 - 3 = 1$$

$$5 \times 4 = 20$$

$$10 \div 5 = 2$$

Depress: **ON** **A/F**

Depress:

Depress:

Depress:

$$4 + 2 =$$

$$4 - 3 =$$

$$5 \times 4 =$$

$$10 \div 5 =$$

DISPLAY SHOWS

Answer: 6.

Answer: 1.

Answer: 20.

Answer: 2.

Percent (%) key

**Percent (%) key**

The automatic percentage function permits all-round use: single percentage calculations, mark-up calculations, ratios, and percentages of a constant. See examples.

**Note:** When using the percent (%) key it is recommended to place the calculator in the floating decimal mode (AM symbol should not appear in display).

**Example:** What is 5% of \$ 115?

$$115 = 100\%$$

? = 5%

Depress: 115  $\times$  5 % Answer: \$ 5.75

**Example:** What percentage is 150 of the total 300?

$$300 = 100\%$$

$$150 = ?\%$$

Depress:  $150 \div 300 \times 100$  Answer: 50.0%

**Example:** What would be the result if 7% were added to the sum of \$ 119?

$$119 = 100\%$$

? = 7%

$$? = 119 + 7\%$$

Depress:  $119 \times 7\%$  or  $119 + 7\%$

Answer: \$ 8.33

Answer: \$ 127.33

## Percent (%) key

**Example:** What is the result if you discount or reduce \$ 165 by 16%?

$$165 = 100\%$$

$$? = 165 - 16\%$$

Depress: 165  $\times$  16  $\%$   $-$  Answer: \$ 138.6 OR

Depress: 165  $-$  16  $\%$   $=$  Answer: \$ 138.6

Calculate the following percentages of the constant 120: 25%, 32%, and 40%

$$120 = 100\%$$

$$? = 25\%$$

$$? = 32\%$$

$$? = 40\%$$

Depress: 120  $\times$  25  $\%$  Answer: 30.

32  $\%$  Answer: 38.4

40  $\%$  Answer: 48.

© 2015 Joerg Wöhrner  
Datamath Calculator Museum

## Constant function

### Calculations with constant function

The constant function feature of the LCB 841 allows the operator to make repetitive calculations using the same number each time without reentering that number for each calculation. The first number entered in a multiplication (multiplicand) and the second number of a division (divisor) automatically become **constant**. The constant is not erased until the multiplication or division key is pressed again. Therefore, the constant number can be recalled by pressing the equal key  $\boxed{=}$  for further calculation without being input again. In using the constant feature it is recommended that the calculator be in the Floating Decimal Mode (F).

**Example:**

$3 \times 3 =$	Depress: 3 $\boxed{\times}$ 3 $\boxed{=}$	Answer: 9.
$3 \times 4 =$	4 $\boxed{=}$	Answer: 12.
$3 \times 5 =$	5 $\boxed{=}$	Answer: 15.
$3 \times 6 =$	6 $\boxed{=}$	Answer: 18.

**Example:**

$25 \div 5 =$	Depress: 25 $\boxed{\div}$ 5 $\boxed{=}$	Answer: 5.
$20 \div 5 =$	20 $\boxed{=}$	Answer: 4.
$15 \div 5 =$	15 $\boxed{=}$	Answer: 3.
$10 \div 5 =$	10 $\boxed{=}$	Answer: 2.

## Three independent memories

For addition and subtraction (like division) the calculator remembers the **second number** entered as a constant.

Example:

$2 + 1 =$

$4 + 1 =$

$7 + 1 =$

$10 + 1 =$

Depress: 2 **+** 1 **=**

4 **=**

7 **=**

10 **=**

DISPLAY SHOWS


Answer: 3.

Answer: 5.

Answer: 8.

Answer: 11.

## Three permanent memories



Your checkbook calculator has three individual storage memories. The balances stored in the three permanent memories will be retained even when the calculator is turned off.

## Using independent memories

### Clearing checkbook memories

To start all memories must be cleared by pressing the memory key in the order shown below:

Example clearing memories:

	FIRST PRESS	SECOND PRESS	CLEARED DISPLAY SHOWS
Check Memory # 1	<b>BAL</b> 1	<b>CHK</b>	0.00
Charge Memory # 2	<b>BAL</b> 2	<b>CHG</b>	AM 1 0.00
Charge Memory # 3	<b>BAL</b> 3	<b>CHG</b>	AM 2 0.00
			AM 3

Each memory may be cleared individually as shown above.

### Use of checking account memory

After clearing, enter your checkbook balance into the calculator and press deposit key **DEP** of memory # 1. The deposit key **DEP** adds to your account balance and the check key **CHK** subtracts from your account balance.

### Checking account deposits

For each deposit, enter the amount of the deposit into the calculator and then press the deposit key **DEP**. The display will automatically show a new checking balance. Caution must be used not to press the deposit key **DEP** twice because the memory balance will be doubled as a second entry.

## Using independent memories

---

### Checks written

For all checks, enter the check amount into the calculator and place into memory by pressing check key **CHK**. Your new checking balance will be automatically shown. Caution, do not depress check key **twice** while your balance remains in the display, or checkbook memory balance will be erased. When checks written exceed the amount of deposits, the memory balance will show a minus sign on the far left side of the display window. This indicates your checking account is overdrawn.

### Use of charge account memory

The charge account memories (# 2 and # 3) are designed to function the same as the checking memory (# 1). The charge memories will allow you to keep the current status of your credit account. The debt (minus) side of the account is represented by the charge key (CHG) and the credit (plus) side of your charge account is represented by the payment key (PMT). After clearing your charge account memories, enter the amount owed on your charge account into the calculator and press the charge (CHG) key of memory # 2 or # 3. A minus sign will be shown in the display window whenever charges exceed payments to indicate your negative balance. The display will show your new balances following each entry. When payments are made to your account, enter the amount into the calculator and press the appropriate payment key (PMT) which will also display your new balance.

## Using independent memories

---

### Other memory uses

The checking/charge memories may be used for many other uses depending on the personal finance needs of the person using the calculator. These are other suggested uses: personal budget, savings accounts, investments, purchases and sales, or monthly payments. If one or more of the calculator memories is not in use, they might be used from time to time to store phone numbers, measurements, special quantities, dollar values, daily calorie counter, or any other numbers which may be needed at a future date.


### Memory grand total key **GT**

The grand total key **GT** is designed to give the operator a grand total of all the memories (# 1, # 2, and # 3). For example, the memory # 1 is being used as a checking account and memories # 2 and # 3 are being used for charge account balances. Depressing the grand total key **GT** would give you the amount of money in checking minus the amount which was owed on the charge accounts.



## Grand total display

Grand Total Example Display:



When any memory balance key (BAL) is pressed, the display will show the balance and the number of the memory (# 1, # 2, or # 3) will show under the balance. If the memory balance is negative, the memory indicator number will flash. When pressing the Grand Total key **GT**, all three of the memory indicator numbers will be shown below the balance displayed. The display indicator numbers will flash to indicate negative balances for respective memories.

## Checking/charge account entry example

### Checking/charge account entry example

Turn machine on.

Clear all memories as instructed.

Leave machine in AM position.

		TO ENTER PRESS	DISPLAY
Checking Account Balance	\$ 950.34	95034 and <b>DEP</b>	950.34
X Charge Account Balance	-240.66	24066 and <b>CHG</b> (# 2)	-240.66
Y Charge Account Balance	-480.45	48045 and <b>CHG</b> (# 3)	-480.45
		<b>GT</b>	229.23

The above entries place your account balances in the three calculator memories. Now enter the following transactions in the checking and charge accounts:

Wrote two checks for \$ 70.55 and \$ 35.49

Charged Account X for \$ 12.55 and \$ 50.67

Made payment on Account X for \$ 250.21

Made payment on Account Y for \$ 250.45

## Checking/charge account entry example

---

The steps for entering the transactions on page 17 into the independent memories of the calculator are as follows:

TO ENTER PRESS	DISPLAY
7055 and <b>CHK</b>	879.79
3549 and <b>CHK</b>	844.30
1255 and <b>CHG</b> (# 2)	-253.21
5067 and <b>CHG</b> (# 2)	-303.88
25021 and <b>PMT</b> (# 2)	-53.67
25045 and <b>PMT</b> (# 3)	-230.00
<b>GT</b>	560.63

NOTE: **GT** display memory indicator symbols appearing under account balances for Memory # 2 and # 3 are flashing to indicate a negative balance in both accounts.

## Budget example

### Budget example:

INCOME	HOUSEHOLD EXPENSES	OTHER EXPENSES
215.00	Rent 250.00	Car 150.80
95.00	Clothing 85.20	Insurance 40.60
595.00	Food 110.70	Medical 60.40
	Utilities 80.10	Other 100.00

The memories could be used for planning out your income and expenses and keeping your monthly budget in your calculator. The following entries would be made to use your calculator for the monthly budget shown above:

### TO CLEAR MEMORIES

PRESS		DISPLAY
<b>BAL 1</b>	<b>CHK</b>	0.00
<b>BAL 2</b>	<b>CHG (# 2)</b>	0.00
<b>BAL 3</b>	<b>CHG (# 3)</b>	0.00

### TO ENTER MONTHLY INCOME

PRESS		DISPLAY
21500 and	<b>DEP</b>	215.00
9500 and	<b>DEP</b>	310.00
59500 and	<b>DEP</b>	905.00
<b>BAL 1</b>		905.00

## Budget example

### TO ENTER MONTHLY HOUSEHOLD EXPENSES

PRESS		DISPLAY
25000 and	CHG (# 2)	-250.00
8520 and	CHG (# 2)	-335.20
11070 and	CHG (# 2)	-445.90
8010 and	CHG (# 2)	-526.00
BAL 2		-526.00

### TO ENTER OTHER EXPENSES

PRESS		DISPLAY
15080 and	CHG (# 3)	-150.80
4060 and	CHG (# 3)	-191.40
6040 and	CHG (# 3)	-251.80
10000 and	CHG (# 3)	-351.80
BAL 3		-351.00

### TO OBTAIN GRAND TOTAL OF ALL MEMORIES (Income Minus Expenses)

PRESS		DISPLAY
GT		27.20

© 2020 Joerg Woerner  
Datamath Calculator Museum

(C) 2020 Joerg Woerner  
Datamath Calculator Museum



---

© 2020 Joerg Woerner  
Datamath Calculator Museum

TECHNICAL ALTERATIONS RESERVED  
PRINTED IN JAPAN

8.80(E)

---